

HoverKart

Model : HK-4



USER MANUAL

IMPORTANT SAFETY NOTICE



WARNING

- This ride on toy is not to be used near swimming pools or ponds, near hills, roadways or stairways.
- Designed only for one rider.
- Parental Supervision required.
- Children should always wear a helmet with elbow and knee pads

ADULT ASSEMBLY REQUIRED

CAUTION: This product contains small parts which are necessary for assembly. Prior to and during assembly of this product, keep small parts out of children's reach. Small parts pose a choke hazard to children under 3 years

Please retain these Instructions for future reference

SAFETY FIRST

- Always: Make sure your child wears a helmet, gloves, elbow and kneepads too.
- Always: Before each ride ensure that the product is safe. Are all the bolt's tight?
- Always: Ensure that your child understands the dangers of the road and crowded areas.
- Always: Only allow use of the product under full adult supervision.
- Always: Ensure that you understand the dangers of the environment where your child is using the product

WARN THE RIDER ABOUT THE BELOW DANGERS


- Never: Use on the road or narrow pavements
- Never: Use near a swimming pool, lake or river.
- Never: Use anywhere near stairways or steps.
- Never: Use on slippery floors.
- Never: Use whilst using a personal stereo or mobile phone.
- Never: Use near hills

PRECAUTIONS


- Like any other product of movement, it can be risky and can result in dangerous situations if not careful
 - Be sure to read the entire manual before using, particularly pay attention to the following information below;
1. Always wear appropriate protective equipment such as helmet, elbow pads, knee pads, long sleeve shirt, gloves, pants.
 2. Always use suitable sports footwear, and do not ride barefoot or in sandals.
 3. Just mount the product on level ground.
 4. Do not use the product on wet soil / rocky / uneven terrains.
 5. Do not use the product at night / in wet or icy conditions.
 6. Do not ride the product on steep hills, especially on long downward slopes, as this could damage the product and cause injury to the rider.

ASSEMBLY INSTRUCTIONS

Screw the seat on to the steel frame



Insert the front frame into the seat frame and lock securely with locking bolt in the desired bolt hole, for the length of the frame.



FULLY ASSEMBLED VIEW



HOW TO USE

Once assembled then attach the product together with the hoverboard with the enclosed attaching Velcro straps.

We advise and recommend that a Silicon cover is used to protect the outer casing of your hoverboard whilst using any HoverKart attachment. We take no responsibility for any aesthetic damage caused to your hoverboard when a protective silicon cover is not used**





+

